

# REPEATER SETUP INSTRUCTIONS

Open blue crate.

Pull each curved leg by pulling out. Make sure legs snap into place.



Remove antenna from blue crate.



Remove antenna mast and slide each section together like a tent-pole.



Screw antenna to the brass fitting. Do not over tighten.



Turn the crate upside down.



Take antenna mast and slip the end into the hole connector in the bottom of the blue crate. Push hard.

Plug into 110 vac outlet and the repeater is ready to go

