

SPRINT PTT Instructions

To Turn on: Press the Red (END) Power button on keypad.

To Turn off: Hold the Red (END) Power button on keypad.



Using the Radio:

- Press the **Contacts key (right top button on keypad)**, then simply scroll up or down using the **navigation keys** to select the desired name.
- Push and Hold the **PTT Button** on the side of the radio and listen for "Connection Tone Sound" before speaking.
Note: This is the go-ahead and speak signal, wait for it, or you will cut off the start of your conversation.
- Then Release the **PTT Button** to listen for a response.

NOTE: For **Group Call**, Select the **group name** from your contacts list. All radios programmed for Group Call will be able to talk & listen at the same time.

Using Headphones / Speaker Mics / Surveillance Kits – Earpieces

Shut off radio, then insert plug straight and firmly into the **Audio Jack**, turn the radio back on.

Note: if you experience a problem accessory or keyed up radio, shut it off disconnect and repeat this procedure.

Charging the Radio

Attach/insert **MICRO USB** charger into the left side of phone (open little latch). The LCD screen will show charging taking place. A full charge will show a full-battery in the LCD screen.

Note: At least 2-Radios must be **Turned On** and on the same channel to be able to talk. If there are no other units on your channel or within range, then the radio will Bonk when you try to talk. This is a good thing, because if your call goes through, you know that someone is on your channel with their unit powered on within range of you, and they received your call.